

BaByliss[®]

**CORDLESS GAS TONG & BRUSH 19MM
2583BU**

SAFETY CAUTIONS

- This appliance should only be used as described within this instruction booklet. Please retain for reference.

IMPORTANT CHILD SAFETY

WARNING! Polythene bags over product or package may be dangerous. To avoid danger of suffocation, keep this wrapper away from babies and children. This bag is not a toy.

WARNING! THIS APPLIANCE GETS HOT!

- **ALWAYS** keep out of reach of children (during and after use and whilst cooling).
- This appliance should not be used, cleaned or maintained by children.
- Always take extra care if used on children or near children.
- Do not use on very young children.

IMPORTANT SAFETY



Danger
Extremely Flammable Gas

Liquefied Gas



Contains Gas under Pressure
May explode if heated

- **WARNING: KEEP OUT OF REACH OF CHILDREN.**
- Store in a well ventilated place.
- Protect from sunlight.
- Store at a temperature not exceeding 50°C / 120°F.
- Do not expose to temperatures exceeding 50°C / 120°F.
- Keep away from heat / sparks / open flames / hot surfaces – No smoking.
- Keep away from animals.
- Do not puncture or incinerate the container, even when empty.
- Contains Butane - EC number 270-704-2.
- Contents 12.5g.

WARNING

- If using aerosol sprays or flammable liquids such as hairspray, allow at least 5 minutes before igniting the tong to let flammable vapours disperse.
- When igniting the appliance, hold it away from hair, face and clothing. Do not ignite while the appliance is in the hair.
- Do not cover the barrel with the hand while igniting.

- Do not leave unattended while switched on.
- Take care to avoid the hot surface of the appliance coming into direct contact with the skin, in particular the eyes, ears, face and neck.
- Allow the appliance to cool before storing away.
- Do not place the appliance on any heat sensitive surface whilst in operation.
- Do not immerse the appliance in water or other liquids.
- Always inspect the appliance before use for noticeable signs of damage, or if the appliance has been dropped. In the event of damage contact the Conair Customer Care Line (refer to the 'UK After Sales Service' section for further information).
- This appliance should not be used by adults whose reduced physical, sensory or mental capabilities, or whose lack of experience and knowledge, might cause a hazard, unless they have been correctly instructed to understand the safe use and hazards involved and are adequately supervised.
- This product complies fully with all appropriate EU and UK Legislation and the Standards relevant to this type and class of appliance. We are an ISO9001:2015 certified company that continually evaluates our Quality Management System performance. If you have any queries regarding product safety and compliance, please contact our Customer Services Department. (See "U.K. After Sales Service" section for further information.)

INSTRUCTIONS FOR USE

- Ensure hair is dry and combed through to remove any tangles. Divide the hair into sections ready for styling.
- Push the 'ON' button and wait for approximately 5 seconds.
- Press the 'START' button on the handle of the appliance several times.
- The light at the end of the barrel should now be on and the tong should begin to heat up.
- Wait for 1 minute, the appliance is now ready for use.
- Pressing the lever, place the appliance midway up a section of hair and spread hair evenly between the lever and barrel.
- Once hair is in place carefully let go of the lever so the hair is held securely between lever and barrel. Gently slide the appliance down to the hair ends.
- Wind the hair around the barrel at a slight angle, so the hair wraps around the barrel in a spiral motion. As you wind the hair around the barrel, ensure the hair is distributed evenly so the entire section is touching the barrel, try not to overlay the hair.
- Hold in place for 5-8 seconds depending on the texture and length of your hair.
- To remove the appliance from the hair, press the lever and pull appliance away.
- Allow the curl to cool before styling.
- Repeat on each hair section.
- After use, push the 'OFF' button and replace the protective heat shield.
- Allow to cool before storing away.

Brush Attachment

- Use the brush attachment to add root volume and shape to styles.
- Make sure the barrel is cool and slide the brush attachment over the barrel until it clicks into place.
- To remove the brush attachment, firstly make sure the barrel is completely cool, then press the black ridged button, located on the bottom of the brush attachment.

- While firmly pressing the black ridged button and slide the brush sleeve off.
- On longer styles, be careful not to overlay the hair around the barrel as this may cause tangling.

To insert or change the Energy Cell

- Remove the base of the appliance handle.
- Remove the cap from the energy cell.
- Place the energy cell into the handle, the top inserted first.
- Twist the energy cell clockwise and screw firmly in place.
- Replace the handle base.

To check level of energy cell

- Check the level of fuel left in the energy cell by looking at the clear base of the cell while in a horizontal position (see figure 1). If cell is empty, replace with a new BaByliss energy cell.

Figure 1



Protective Heat Shield

- After styling, ensure the appliance is switched off and cool.
- Remove the brush attachment from the barrel.
- Press the lever release button, this will lift the clip that will hold the heat shield in place.
- Slide the heat shield down over the barrel until it slots into place under the clip.
- Release the lever button, the clip will then lock the heat shield in place.

NOTE: The brush attachment must be removed before the protective heat shield can be placed onto the barrel.

Air Travel

Please note that only one unit containing an energy cell may be carried per person aboard an aircraft inside your check-in-bags. Additional energy cells are not permitted. The protective heat shield must be securely in position over the heating element. This is subject to the individual airline's discretion. Please check with the airline before you travel.

For more information on this appliance visit www.babylicss.co.uk

UK GUARANTEE

The Conair Group Ltd, Unit 3, Waterfront Business Park, Fleet, GU51 3TW

This BaByliss appliance is guaranteed for consumer use for 3 years and is only valid within the United Kingdom.

This guarantee covers consumer use only **i.e.** defects occurring under normal use within the home from date of purchase or date of delivery, whichever is later.

If the product develops a fault due to defects in materials or manufacture **within 12 months** from the date of purchase, to avoid delays and unnecessary inconvenience, where possible please return the product to the point of purchase for an exchange.

If the product develops a fault due to defects in materials or manufacture **after 12 months** from the date of purchase, and within the guarantee period, Conair UK After Sales Service will repair or replace the product.

Exclusions

This guarantee will no longer be valid meaning that The Conair Group Ltd will not be liable to repair or replace your product where:

- 1.) The appliance has been used on a voltage supply other than that which is marked on the product, or advised within this instruction booklet
- 2.) The appliance has been purchased from an unauthorised stockist*
- 3.) The appliance is used for professional / non domestic usage
- 4.) Repairs or alterations have been attempted by unauthorised persons
- 5.) The failure of the appliance is a direct result of misuse
- 6.) The failure is a result of not following the instructions for use

This guarantee does not cover any cosmetic damage due to misuse of the product nor any damage to persons or property that occurs because of product misuse.

*unauthorised stockists include, but are not limited to online auction sites, private sellers and those selling second hand goods, refurbished products etc

Please contact the Conair Customer Care Line on 03705 133 191 (09:00 to 17:00 Monday to Friday) or e-mail ukinfo@conair.com for further information on authorised stockists.

It is important to retain your proof of purchase. We recommend attaching your receipt to this page.

Even where a refund may be applicable, no refund will be provided without a valid receipt or proof of purchase, we will only be able to offer a repair or replacement service. Please note this does not apply if the product was purchased directly from The Conair Group Ltd.

Guarantees on replacement products run from the original purchase date or date of delivery, whichever is later, and **not** from the date of replacement.

This guarantee is an additional benefit and does not affect your statutory rights as a consumer.

If you have any queries regarding this guarantee please contact the Conair Customer Care Line on 03705 133 191 (09:00 to 17:00 Monday to Friday) or e-mail ukinfo@conair.com

UK AFTER SALES SERVICE

For further advice on using the appliance or should you need to return your product, please contact the Conair Customer Care Line on 03705 133 191 (09:00 to 17:00 Monday to Friday) or e-mail your enquiry to ukinfo@conair.com

Return address:

Customer Care Centre
Conair Logistics
Unit 4, Revolution Park
Buckshaw Avenue
Buckshaw Village
Chorley
PR7 7DW

Please enclose your returns number, name and address details, together with a copy of proof of purchase and details of the fault.

Please note this Instruction Booklet is not the guarantee.

SAFE DISPOSAL



The  symbol on the product or on its packaging indicates that this product may not be treated as household waste. Instead it should be handed to an appropriate collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. For more detailed information about the recycling of this product, please contact your local council office or your household waste disposal service.

Fully depleted Gas Cells can be recycled. Please contact your local recycling centre for more information on the safe disposal of this product. **ONLY** fully depleted Gas cells can be recycled.

